


















	Kollisjonspute		Lagret gasspumpe		Forspenning av setebelster		SRS kontrollenhet		Aktiv fotjengerbeskyttelse
	Automatisk veltbeskyttelse system		Gasstødemper Forhåndsbelastet fjær		Høy styrkesone		Sone som krever spesialopmerksomhet		
	Lavt batteri Spenning		Ultra kondensator, Lav spenning		Drivstofftank		Gasstank		Sikkerhetsventil
	Høy spenning batteripakke		Høy spenning effekt kabel/komponent		Høy spenning frakobling		Sikringsboks deaktiverer høyspennings system		Ultra kondensator, høy spenning
	gassledning								

1. Identifisering / Gjekkjenning



Lydløs bevegelse eller øyeblikkelig omstartfunksjon er tilgjengelig til bilen er helt slått av



Modellnavn




Merkenavn


2. Immobilisering / Stabilisering / Løfting

A. IMMOBILISERE BILE

1. Sett bilen gir til P;
2. Slå på varselblikkerne på midtkonsollen.



B. ØFTEPUNKTER:





- Egnede løftepunkter
- Egnede punkter på siden av bilen
- Høyspentbatteri

3. Aktivere direkte fare / Sikkerhetsforskrifter






Vær oppmerksom på at ikke alle høyspente komponenter er merket. Bruk alltid passende verneutstyr (gummiisolerte hansker / isolerte gummisko / verktøy med isolerende beskyttelsesdeksel / vernebriller). Ikke prøv å åpne høyspentbatteriet.

DEN VIKTIGSTE DEAKTIVERINGSMETODEN




TILGANG TIL 12V-BATTERIET






4. Ti ang for passasjerer og fører




Setejustering (elektrisk)




Utvendig dørhåndtak



Utgang for 3. seterad



Lengdejustering av sete



Justering av rattstammen



Dørhåndtak

Glasstyper:

Laminert glass



Herdet glass

5. La et energi / Væsker / Gasser / Faste stoffer

		12V
		350V
		1300g

6. I ti elle brann


BRUK STORE MENGDER VANN

BATTERIANTENNELSE!

IKKE SENK BILEN NED I VANN FOR Å SLUKKE BATTERIET

7. I tilfelle nedsenkning i vann

Velt bilen over på den ene siden for å la vannet renne ut av bilen og høyspenningsbatteriet.


Bruk egnet personlig verneutstyr. Fjern bilen fra vannet, og fortsett med normal frakoblet høyspenning (se kapittel 3). Biler som er nedsenket i saltvann må håndteres med større potensiell risiko for brann i høyspenningsbatteriet.

8. Tauing / Transportering / lagring


LAGRES I EN SIKKER AVSTAND FRA ANDRE KJØRETØY!




BATTERIANTENNELSE!



Tau-/transportmetode



Oppbevaring av kroken



Plassering av kroken


9. Viktig tilleggsinformasjon

Informasjon om produsenten JAC Automobile Group Co., Ltd (China)

For mer informasjon, se «Nødhjelpsguide».

10. Forklaring av piktogrammene som er brukt

	Advarsel for høyspenning		Brannfarlig
	Forsiktig		Farlig for den menneskelige helse
	Klima-anleggskomponent		Akutt forgiftning
	Elektrisk bil		Etsende
	Panser		Gasser under trykk
	Bagasjerom		Eksplodivt
	Bruk termisk infrarødt kamera		Bruk vann for å slukke brannen



Li-ion
350V

	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Pedestrian protection active system
	Automatic rollover protection system		Gas strut/Preloaded spring		High strength zone		Zone requiring special attention		
	Battery Low Voltage		Ultra capacitor, low voltage		Fuel tank		Gas tank		Safety valve
	High voltage Battery pack		High voltage power cable/component		High voltage disconnect		Fuse box disabling high voltage system		Ultra capacitor, high voltage
	Gas line								

1. Identification/recognition



Silent movement or instant restart capability exists until vehicle is fully shut down



Model name




Brand name


2. Immobilization / Stabilisation / Lifting

A. IMMOBILIZE THE VEHICLE

1. Shift the vehicle to P gear;
2. Turn on the hazard warning lamp on the central console.



B. LIFTING POINTS:



Appropriate lifting points

Appropriate points vehicle on side

High voltage battery



3. Disable Direct Hazards / Safety Regulations






Be aware that not every high voltage component is labelled.


Always wear the appropriate PPE (Rubber insulated gloves / insulated rubber shoes / tools with insulating protective cover / goggles). Do not attempt to open the high voltage battery.

MAIN DISABLING METHOD



ACCESS TO 12V BATTERY






4. Access to the Occupants



Seat adjustment (electric)



Exterior door handle


 Exit to 3rd seat


Long slide adjustment



Steering column adjustment



Door latch

Glass types:

5. Stored Energy / Liquids / Gases / Solids

		12V
		350V
		1300g

6. In Case of Fire
USE LARGE AMOUNTS OF WATER

BATTERY RE-IGNITION!
DO NOT SUBMERGE VEHICLE TO EXTINGUISH BATTERY

7. In Case of Submersion

Tilt the vehicle to one side to allow water to drain out of the vehicle and the high voltage battery.


Wear appropriate PPE. Remove the vehicle from the water and continue with normal high voltage disconnection (see chapter 3). Vehicles submerged in salt water should be handled with a greater potential risk of a high voltage battery fire.

8. Towing / Transportation / Storage


STORE AT SAFE DISTANCE FROM OTHER VEHICLES!



BATTERY RE-IGNITION!



Towing/transportation method



Hook storage



Hook location

9. Important Additional Information

Manufacturer information JAC Automobile Group Co., Ltd (China)

For further details, please refer to "Emergency Response Guide".

10. Explanation of Pictograms Used

	Warning high voltage		Flammable
	Caution		Hazardous to the human health
	Air-conditioning component		Acute toxicity
	Electric Vehicle		Corrosives
	Bonnet		Gases under pressure
	Boot		Explosive
	Use thermal Infrared camera		Use water to extinguish the fire